

Troubleshooting

Before investigating individual units for faults, it is important to check that the system wiring is fault free. Earth faults on data loops or interface zone wiring may cause communication errors.

Many fault conditions are the result of simple wiring errors. Check all connections to the unit. Do not overtighten screws when mounting the backbox as this will cause distortion of the moulding.

Fault Finding

| | Problem | Possible Cause |
|--|------------------------|---|
| | No response or missing | Incorrect address setting Incorrect loop wiring |
| | Alarm condition | Glass or element incorrectly fitted or broken Test key not removed |

Routine testing

Insert the test key into the hole at the bottom of the call point and push home. Observe routine test requirements as specified in the applicable local codes.

Resetting

After testing reset the call point by removing the test key and pushing up the front cover until it clicks home.

Transparent hinged cover

To provide additional protection against accidental operation, a transparent hinged cover with a locking tag, part no 26729-152 is available, which can be fitted to the manual call point included with this guide.

Please note that the call point does not conform to EN54-11 : 2001 when this lid is fitted and secured with the locking tag supplied.

For further information, please refer to the XP95 Engineering Product Guide, PP1039. For isolator operation information refer to PP2090. Both documents are available on request.



XP95 Manual Call Point (EN54) Installation Guide

General

The XP95 Manual Call Point (EN54) is available in two versions:

- part no. 55100-905, non-isolated red Manual Call Point with a standard backbox for surface wiring.
- part no. 55100-908, isolated red Manual Call Point with a standard backbox for surface wiring.

Installation

1. Fit the backbox (**Fig 1**) to the wall.
2. Run the cables from the loop into the backbox and connect them to the terminal blocks as shown in **Fig 2**. Ensure that functional earth/screen continuity is maintained. Screens should be connected to the yellow terminal block marked 1–4 on the black PCB cover.
3. If a loop continuity test is to be done, it should be carried out before securing the call point to the backbox (step 5). Insert the continuity links supplied with the backbox (**Fig 3**) into the terminal blocks before testing. After testing for continuity remove the connectors and store for re-use.
4. Set the unit address on the DIL switch in accordance with the address table overleaf.
5. Unlock the small front cover by inserting the forked key and pushing it home. Remove key, slide the cover down and remove the deformable element. Connect the terminal blocks as shown in **Fig. 2**, secure the call point to the backbox and refit the deformable element as required. Finally, replace the front cover in the reverse order in which it was removed and push it up until it locks.

The XP95 Manual Call Point (EN54) is a 'type A' call point and is suitable for indoor use only. For flush mounting, a suitable single-gang mounting box (minimum 20mm depth) is required. XP95 glasses are also available, part no. 26729-154 (pack of 5)

Wiring Details

All wiring terminals accept solid or stranded cables up to 2.5mm².




Fig 1 Backbox




Fig 2 Terminal block connections




Fig 3 Continuity link




Fig 4 Terminal blocks fitted and address 78 set

Maximum Loop Current Consumption at 24V

typical switch-on surge, 2s typical
quiescent and alarm
LED illuminated

750µA
100µA
4mA

LED Indicator

- ⊙ Illuminated red (under CIE control) when call point is operated
- ⊙ Illuminated yellow when short-circuit isolator has operated (version with integrated isolator)

Address Setting

The address of the Manual Call Point is set using the DIP switch. All segments of the switch are set to 0 or 1, using a small screwdriver or similar tool.

A complete list of address settings is shown in the following table.

| addr | DIL switch setting 1234567 | addr | DIL switch setting 1234567 | addr | DIL switch setting 1234567 | addr | DIL switch setting 1234567 | addr | DIL switch setting 1234567 |
|------|----------------------------|------|----------------------------|------|----------------------------|------|----------------------------|------|----------------------------|
| 1 | 1000000 | 11 | 1101000 | 21 | 1010100 | 31 | 1111100 | 41 | 1001010 |
| 2 | 0100000 | 12 | 0011000 | 22 | 0110100 | 32 | 0000010 | 42 | 0101010 |
| 3 | 1100000 | 13 | 1011000 | 23 | 1110100 | 33 | 1000010 | 43 | 1101010 |
| 4 | 0010000 | 14 | 0111000 | 24 | 0001100 | 34 | 0100010 | 44 | 0011010 |
| 5 | 1010000 | 15 | 1111000 | 25 | 1001100 | 35 | 1000010 | 45 | 1011010 |
| 6 | 0110000 | 16 | 0000100 | 26 | 0101100 | 36 | 0010010 | 46 | 0111010 |
| 7 | 1110000 | 17 | 1000100 | 27 | 1101100 | 37 | 1010010 | 47 | 1111010 |
| 8 | 0001000 | 18 | 0100100 | 28 | 0011100 | 38 | 0110010 | 48 | 0000110 |
| 9 | 1001000 | 19 | 1100100 | 29 | 1011100 | 39 | 1110010 | 49 | 1000110 |
| 10 | 0101000 | 20 | 0010100 | 30 | 0111100 | 40 | 0001010 | 50 | 0100110 |
| 51 | 1100110 | 61 | 1011110 | 71 | 1110001 | 81 | 1000101 | 91 | 1101101 |
| 52 | 0010110 | 62 | 0111110 | 72 | 0001001 | 82 | 0100101 | 92 | 0011101 |
| 53 | 1010110 | 63 | 1111110 | 73 | 1001001 | 83 | 1100101 | 93 | 1011101 |
| 54 | 0110110 | 64 | 0000001 | 74 | 0101001 | 84 | 0010101 | 94 | 0111101 |
| 55 | 1110110 | 65 | 1000001 | 75 | 1101001 | 85 | 1010101 | 95 | 1111101 |
| 56 | 0001110 | 66 | 0100001 | 76 | 0011001 | 86 | 0110101 | 96 | 0000011 |
| 57 | 1001110 | 67 | 1100001 | 77 | 1011001 | 87 | 1110101 | 97 | 1000011 |
| 58 | 0101110 | 68 | 0010001 | 78 | 0111001 | 88 | 0001101 | 98 | 0100011 |
| 59 | 1101110 | 69 | 1010001 | 79 | 1111001 | 89 | 1001101 | 99 | 1100011 |
| 60 | 0011110 | 70 | 0110001 | 80 | 0000101 | 90 | 0101101 | 100 | 0010011 |
| 101 | 1010011 | 106 | 0101011 | 111 | 1111011 | 116 | 0010111 | 121 | 1001111 |
| 102 | 0110011 | 107 | 1101011 | 112 | 0000111 | 117 | 1010111 | 122 | 0101111 |
| 103 | 1110011 | 108 | 0011011 | 113 | 1000111 | 118 | 0110111 | 123 | 1101111 |
| 104 | 0001011 | 109 | 1011011 | 114 | 0100111 | 119 | 1110111 | 124 | 0011111 |
| 105 | 1001011 | 110 | 0111011 | 115 | 1100111 | 120 | 0001111 | 125 | 1011111 |
| | | | | | | | | 126 | 0111111 |

The switch in Fig 4 shows address setting 78 as an example of how to set the address

Commissioning

The installation must conform to BS5839-1 (or applicable local codes).

Ensure that a glass or deformable element is fitted to each call point before testing. Use the test key provided to check the operation of each device. An XP95 Test Set, part no. 55000-870, may be used to carry out functional testing of individual units. The test set can also perform data integrity tests of an entire system.

Note: the test key must remain inserted for at least 2 seconds to ensure the correct CIE response.