



SAFETY POSTER INSTRUCTIONS FOR THE SAFE HANDLING OF YOUR CUTTING TOOL

martor


SECUMAX EASYSAFE




USAGE



For best results, cut plastic strapping band **diagonally** (at a 45° angle).



The **plastic guide** flattens the material being cut, making thin foil and paper easy to work with.



To use the **tape splitter** located at the head of the cutter, simply turn the cutter over.



Use the locking key to **lock the blade change** mechanism ("lock closed").


BLADE CHANGE



Use the locking key to **unlock the blade change** mechanism ("lock open").



With two fingers, **disengage the blade holder** and swing it open.




You can now lift up the blade cover to either **rotate or change** the blade.




Finally, close the blade cover and push the blade holder **back into the handle**. With a click, everything is in place.

PROTECTION OF USER




The concealed blade provides a maximum protection from **cut injuries**.

PROTECTION OF GOODS




The concealed blade **won't come into contact with your goods** either.

DISPOSAL



Your SAFEBOX is the best place to store **used blades**.



When the SAFEBOX is full, **empty all contents** into your RECYCLING BOX.

Please note: to ensure your product always functions flawlessly, regularly remove any build-up of cutting material.