


Premier EX Pro Output Expansion Relay PCBs

The EX-OER output expansion relay board can be mounted inside the EX Pro to provide voltage-free changeover relay contacts for reset, mode, discharged, abort and additional 1st stage, 2nd stage output and extract fan output. One unit can be used.



Model Number	Description
EX-OER3	Premier EX Pro Output Expansion Relay PCB (3 Outputs for Abort, Automatic Mode & Manual Mode)
EX-OER8	Premier EX Pro Output Expansion Relay PCB (8 Outputs for Reset, Automatic Mode, Manual Mode, Discharged, Abort and Additional 1st stage, 2nd Stage Output and Extract Fan Output)